



There is a QR sticker on the face of your safe that looks like this. If you scan this QR code it will take you to the latest instructions and a series of how to videos that details the instructions below.

If there is no QR code on the safe go to <https://dav.group/qmbfy>

## INSTRUCTIONS

### FEATURES

#### LOW BATTERY WARNING

- + **Low Battery Warning** - Keypad will repeat signal 5 times during lock opening. This warning indicates that the battery is low and should be replaced.
- + **Critical Low Battery Warning** - Keypad respond to any key press by repeating this signal 10 times. This warning indicates that the lock cannot be safely operated. The batteries must be replaced before the lock will operate.

#### WRONG TRY PENALTY

- + Four (4) consecutive invalid combination initiates five (5) minute delay period the keypad will not respond to any button presses and the keypad will flash once every 10 seconds while the lock is counting penalty time.

#### USER COMBINATION

- + Open Lock
- + Change Combination

#### AUDIO AND VISUAL SIGNAL

- + Double signal - two (2) LED flashes and two (2) beeps - indicates entry is valid or accepted.
- + Triple signal - three (3) LED flashes and three (3) beeps - indicates invalid or not accepted.

### OPENING THE LOCK

1. Enter valid six (6) digit combination (the default code is 123456). The lock will signal a valid combination entry with a double beep.
2. Within four (4) seconds, turn the keypad to the open position (clockwise).
3. Pull door open.
4. Close the door, and check the locked status of the container with the handle.

- + **Invalid Combination Entry** - Lock will signal three (3) times.
- + **Security Considerations** - On safes using more than one lock the swing bolt must lock first.

### CHANGING USER COMBINATION

#### ALWAYS PERFORM THIS OPERATION WITH THE DOOR OPEN

1. Enter "zero" six times.
2. Enter your existing six (6) digit combination one time.
3. Enter your NEW six (6) digit combination two times.
4. If a mistake is made wait thirty (30) seconds and repeat steps 1 - 3.
5. Test lock operation several times before closing the door.

**CAUTION:** When selecting a combination do not use birthday or other predictable data that could give correlation between the user and combination. Keep the combination secret.

- + **Valid Combination Entry** - Double signal after valid six (6) digit combination is entered.
- + **Invalid Combination Entry** - Triple signal indicates the old combination is still valid.



### WRONG TRY PENALTY

- + Entry of four (4) consecutive invalid combinations starts a five (5) minute delay period.  
- LED flashes red at ten (10) second intervals.
- + At the end of the delay period, two (2) more consecutive invalid combinations will restart the five (5) minute delay period.

### BATTERY LOW WARNING

- + Repeated LED flashing and beeping during an opening indicates that the battery is low and needs immediate replacement.
- + Uses two (2) 9-Volt alkaline battery only. (Example: Duracell™ or Energizer™ alkaline batteries.) The replacement of batteries at least once annually is recommended.


There are two x 9-volt batteries located in the keypad. These are in the battery draw that is located on the side of your keypad between 3 and 6 o'clock.



### To access the battery drawer to replace the batteries

1. Depress the battery drawer button located at 6 o'clock on the side of the keypad  
- This will release the drawer and allow you to slide out the battery drawer.
2. Remove and dispose of the old batteries
3. Replace the two 9-volt batteries with two new alkaline batteries



 The LA GARD 700 series safe locks have been designed for optimal operation with Alkaline Duracell or Energizer batteries. **Use of other battery brands may cause issues with the lock operation.**

4. Insert the new 9-volt batteries into the battery drawer noting the polarity  
- You will note the + and - in the plastic moulding
  - The large terminal on the battery is the - symbol
  - The small terminal on the battery is the + symbol
5. Once the batteries are inserted correctly into the drawer, slide the battery draw back into place within the keypad
6. Test correct operation.